

Preface

This IntelliBar User Guide contains the information necessary to set up and maintain the IntelliBar Models 48, 412, and 88 bar code printers.*

The manual is organized as follows:

A list of the abbreviations used in this manual follows the preface.

Section 1 General Information provides an overview of the IntelliBar printers. This chapter explains the main features of the printers and their options. This section also lists printer specifications.

Section 2 Setup describes how to set up the printer.

Section 3 Unit Operation describes control panel buttons, status messages, menus, and memory settings for the printer.

Section 4 Options provides information on the various IntelliBar user and dealer installable options, including installation procedures.

Section 5 Cleaning and Adjustments contains instructions for cleaning and adjusting the printer.

Section 6 Troubleshooting provides troubleshooting aids that include error codes, test samples, and troubleshooting procedures. This section also contains information on **getting service and support** and **printer warranty** terms and limitations.

Appendix A Packing provides packing information.

The **Glossary** at the end of this manual provides a list of IntelliBar and bar code printing terms and briefly defines each one.

NOTE: For updates on IntelliBar printer specifications and other information about *IntelliTech* International, Inc. products, visit our web site at <http://www.intellibar.com>.

*"This information is subject to change without notice. This information is provided "as is" without either express or implied warranty. *IntelliTech* International, Inc. disclaims any and all warranties with regard to this information. *IntelliTech* shall not be liable in any event for any special, indirect or consequential damages or any damages whatsoever resulting from loss of data, profits or use, for any reason or in any action, arising out of or in connection with the use or performance of this information. "
